# **ACCESSORIES**

## **TORQUE WRENCHES**

2 Position easy-to-use specialized torque wrenches for tightening tool holders to the correct ft/lb per collet size.

## **TORQUE WRENCH**

**PART NUMBER** 

XW-1000-ER40

XW-1000-ER32

XW-1000-ER25

XW-1000-ER16

(Use with X-Station)



LDER TIGHTENING			
B POSITIONS	COMPATIBLE STATION		
88 & 147	XS-1010-63		
51 & 95	XS-1020-30		
40 & 66	XS-1010-32		
21	XS-1010-25		



## **CHANGING STATIONS**

**SIZE** 

**ER40** 

ER32

ER25

**ER16** 

Designed to hold your tool holder in place while you torque the collet nut to the appropriate torque setting. Using our CNC tool holder tightening station and wrench will allow you to tighten your tool holders to the correct torque spec for the collet used, leading to longer tool and spindle bearing life.

### X-STATION

(Best when used with X-Edge torque wrench)

FOR: HOLDING TOOL HOLDERS			
PART NUMBER	TAPER	COMPATIBLE WRENCH	
XS-1010-63	HSK 63	XW-1000-ER40	
XS-1010-32	HSK 32	XW-1000-ER25	
XS-1010-25	HSK 25	XW-1000-ER16	
XS-1020-30	ISO 30	XW-1000-ER32	
XS-1020-25	ISO 25	n/a	



#### X-STATION REPLACEMENT BEARINGS

FOR: X-STATION					
PART NUMBER	TAPER	COMPATIBLE X-STATION			
XSBH63	HSK 63	XS-1010-63			
XSBH32	HSK 32	XS-1010-32			



www.xedgetools.com 19